



We help you shine.™



EQUINOX™

UHS FLOOR COATING

PROQUIP NZ LTD - 0800 686 284 - www.proquipnz.co.nz

103 EQUINOX™

UHS FLOOR COATING

A high solids formula for ultra high speed ("UHS") applications. Produces a coating so tough that it significantly reduces the frequency of re-coating and burnishing. Provides excellent gloss, scuff resistance and long lasting durability.

Product Packaging*



PROD CODE: 103FSE
SIZE: 2.64 US gallons (10 liters)
ORDER QTY: 2 per case

Product Data:

Description	Polymer emulsion	Coverage	2500 to 3000 ft ² /gal 61 to 74 m ² /liter	Buffability	Excellent
Appearance	Milky white	Fragrance	Slight ammoniacal	Removability ASTM D1792-06	Excellent
Non-volatile solids ASTM D2834-95 (2008)	22%	Slip Resistance UL TM410	Meets requirements	Detergent Resistance ASTM D3207-92 (2008)	Excellent
Specular Gloss (60°) ASTM D1455-87 (2008)	>85	Shelf Life ASTM D1791-93 (2008)	1 year	Drying Time	About 30 minutes
Viscosity (Brookfield) @ 68°F (20°C)	<10 centipoise	Density ASTM D1475-98 (2008)	8.6 lb/gal @ 68°F 1.03 kg/L @ 20°C	Freeze/Thaw ASTM D3209-93 (2008)	Passes 3 cycles

MSDS sheets available for download at www.pioneer-eclipse.com



Floor Coating and Finishing materials
as to slip resistance only. 42E6

Distributed in New Zealand by



Our **toughest** and most
durable floor coating.

Recommended Floor Surfaces:

Vinyl composition tile ("VCT"), terrazzo, marble, concrete, quarry tile.
Ideal for floors where maintenance occurs 4-7 days per week.

Directions for use: INITIAL APPLICATION

1. Remove old coating and sealer.
2. Neutralize floor using a neutral cleaner or EnviroStar Green™ All Purpose Neutralizer.
3. Rinse floor again with clean, cold water and allow to dry.
OPTIONAL: Apply 2 thin coats of sealer to high-traffic areas and old or porous floors.
4. Apply 4-6 coats of EQUINOX Floor Coating with a clean, synthetic mop.
NOTE: Do not exceed an initial application of a combined 6 coats of coating and sealer.
5. Allow floor to dry thoroughly between coats and prior to burnishing.
NOTE: To prevent contamination do not pour unused product from bucket into original container.

Directions for use: ROUTINE MAINTENANCE

1. Sweep floor daily with a dust mop.
2. To clean floor use mop or scrubber with neutral cleaner.
3. Restore shine as needed with floor maintainer.
4. Burnish as desired with ultra high speed machine and pad.
5. As needed, perform a deep scrub and re-coat applying an additional 1-2 coats of EQUINOX Floor Coating.
6. Allow floor to dry thoroughly between coats and prior to burnishing.
7. Strip floor when desired results cannot be achieved with routine maintenance.

VOC 0.06%
(40 CFR Part 59 Subpart C)

Pioneer Eclipse®

©2011 Amano Pioneer Eclipse Corporation® • 1 Eclipse Road • PO Box 909 • Sparta, NC 28675 USA
1-800-367-3550 • 1-336-372-8080 • Fax: 1-336-372-2895 • www.pioneer-eclipse.com